


## OWNER'S MANUAL

You may download translated versions of this manual at [www.ctrl-eyewear.com](http://www.ctrl-eyewear.com)  
Please follow the care and usage instructions in this manual to ensure optimal performance from your CTRL™ Eyewear.



## DIRECTIONS OF USE

### GLOSSARY OF TERMS

ACTIVATE: Turn on; tint | DEACTIVATE: Turn off; clear

CTRL™ electronic-tinting eyewear changes instantly between two levels of tint (on or off) by either a quick touch of the button, or automatically via the built-in light sensor. These tint levels are fixed and cannot be adjusted by the user. The eyewear comes pre-programmed with a standard light threshold setting for use in automatic mode. You have the option to re-program the light threshold if you determine that it does not automatically activate or deactivate to your liking (see "Adjust Light Threshold" below).

### TO OPERATE IN MANUAL MODE:

Quickly press and release the button to activate or deactivate the tint of the eyewear.

### TO OPERATE IN AUTOMATIC MODE:

CTRL™ Eyewear is designed to automatically tint in the presence of an activating light. To switch the system to automatic mode, simply press and hold the button for approximately three (3) seconds. The lens will flash two (2) times to indicate it has been switched into automatic mode. Release the button. The eyewear is now set for automatic use.

### TO EXIT AUTOMATIC MODE (AND ENTER MANUAL MODE):

Quickly press the button once to revert back to manual mode. Note: The lens will deactivate upon exiting automatic mode.

### TO ADJUST LIGHT THRESHOLD:

First, switch the eyewear to automatic mode. Choose an ambient area of light that would be similar to where you would prefer the eyewear to activate. Put the eyewear on and stand in your desired lighting condition. Press & hold the button for approximately four (4) seconds. After four seconds, the lens will flash three (3) times to indicate the system has re-calibrated its sensor to your desired light threshold. Light that is as bright as, or brighter than, your selected ambient lighting will now trigger the sensor. The electronics will store this custom threshold until it is either re-programmed or reset to its factory setting. NOTE: Be sure to keep the area around the photo sensor clear and open to the light source. If your finger is covering the light sensor while setting the light threshold, the eyewear will stay activated most of the time and only switch when it is very dark. Do NOT attempt to change the light threshold when moving.

### FOR A FACTORY RESET:

A factory reset can be performed in either manual or automatic mode. Press and hold the button for approximately six (6) seconds. The lens will cycle through (2) sets of flashing. After the second set of flashing, the eyewear will be restored to its original factory settings.

## CHARGING

Gently peel back the Micro-USB cover to connect the Micro-USB cable into the electronics port. Charge by using either a wall adapter or computer. The lens will stay activated while charging, and the button will be inoperable. When the battery is fully charged, the lens will deactivate. It is recommended to fully charge before each use. A depleted battery can take up to 2 hours to fully charge. \*Do not store eyewear connected to a charging source.

**WARNING!** IT IS YOUR RESPONSIBILITY TO DETERMINE THE SUITABILITY OF THIS PRODUCT FOR ITS INTENDED USE, AND YOU USE THIS PRODUCT AT YOUR OWN RISK. IF AT ANY TIME YOU BELIEVE THAT YOUR CTRL™ EYEWEAR IS NOT PERFORMING PROPERLY, DISCONTINUE USE OF THE EYEWEAR AT ONCE. THIS PRODUCT IS NOT RECOMMENDED FOR USE AT NIGHT OR IN TEMPERATURES BELOW -10°C (14°F) OR ABOVE 45°C (113°F). USE AT YOUR OWN DISCRETION.

## CLEANING & CARE

Clean with warm water, mild detergent, and a soft cloth. For stubborn residues clean with a household glass cleaner. Do not use cleaners which contain moisturizers, abrasives, strong acids, or caustics. Do not immerse the eyewear in liquids, as this may impact the function of the electronics. Do not leave this product in direct sunlight when not in use. Doing so will degrade the longevity of your eyewear.

---

## RETURN POLICY

---

CTRL™ Eyewear is committed to creating the best performance products in the industry and we are always interested in receiving input from our valued customers. If you experience a problem with one of our products we want to know about it.

You may return any new, unopened product for a full refund or exchange within (30) days of purchase. Please contact your retailer if you purchased a product in a store or a webshop online (other than [www.ctrl-eyewear.com](http://www.ctrl-eyewear.com)). Special order returns are at our discretion on a case-by-case basis. The total refund amount is for the cost of your product, excluding shipping. Please contact CTRL Eyewear Customer Service for an RMA (Return Merchandise Authorization) number and specific return and shipping instructions by emailing [support@ctrl-eyewear.com](mailto:support@ctrl-eyewear.com). Products returned for full refund must be in new condition and in original packaging. A purchase receipt must be provided with the return of any product. Products returned to CTRL Eyewear without notification will not be eligible for a refund or exchange. The shipping and duty charges for returning a product are the sole responsibility of the customer.

Although we do not require you to register your new product, it is important to keep the following information to obtain warranty service. In the event that you would like to file a claim, CTRL Eyewear Customer Service **will require**:

- **SERIAL NO.** Found on the retail box, next to the UPC code
- **MODEL NO.**
- **ORIGINAL PURCHASE RECEIPT**
- **FIRST & LAST NAME**
- **TELEPHONE NUMBER**
- **EMAIL & SHIPPING ADDRESS**

---

## LIMITED WARRANTY

---

All CTRL™ products are warranted for a period six (6) months from the date of purchase against any defects in materials and workmanship. If you find a defect within six (6) months after purchase, we kindly request you return your product to CTRL Eyewear. We will then evaluate your claim and, based on our findings and at our option, repair or replace any CTRL™ product that does not conform to the Limited Warranty.

Please contact your retailer if you purchased a product in a store or a webshop online (other than [www.ctrl-eyewear.com](http://www.ctrl-eyewear.com)). In order to obtain limited warranty service by CTRL Eyewear, the following procedures must be followed: Contact Customer Service for an RMA (Return Merchandise Authorization) number, and specific return and shipping instructions, by emailing [support@ctrl-eyewear.com](mailto:support@ctrl-eyewear.com). The CTRL™ product must be returned with a purchase receipt for warranty service. Products returned to CTRL Eyewear without notification will not be eligible for limited warranty service. The shipping and duty charges for returning the product are the responsibility of the customer.

**Online Auction Purchases:** Products purchased through online auctions (this does not apply to purchases made on [www.ctrl-eyewear.com](http://www.ctrl-eyewear.com)) are not eligible for warranty coverage. Online auction confirmations are not accepted for warranty verification. To obtain warranty service, an original or copy of the sales receipt from the original retailer is required. CTRL Eyewear will not replace missing components from any package purchased through an online auction.

### EXCLUSIONS

The Limited Warranty set forth above applies only to CTRL™ products manufactured by or for CTRL Eyewear B.V. and that bear the "CTRL" trademark, trade name, or logo. The Limited Warranty does not apply to any non-CTRL™ products. Please check the relevant packaging for any relevant third party warranty information.

The Return Policy and Limited Warranty does not apply: (a) to consumable parts, such as batteries, unless damage has occurred due to a defect in materials or workmanship; (b) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (c) to damage caused by operating the product outside the permitted or intended uses described by CTRL Eyewear; (d) to damage caused by ordinary wear and tear; (e) to damage caused by service or repair performed by anyone who is not a representative of CTRL Eyewear; or (e) to damage arising from failure to follow instructions relating to the product's use or installation.

EXCEPT AS SET FORTH IN THE LIMITED WARRANTY, ALL PRODUCTS AND SERVICES MADE AVAILABLE TO YOU BY CTRL EYEWEAR ARE PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, CTRL EYEWEAR EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT, WITH RESPECT TO ALL PRODUCTS AND SERVICES MADE AVAILABLE TO YOU BY CTRL EYEWEAR. NO INFORMATION OR ADVICE OBTAINED THROUGH THE CTRL™ WEBSITE, OR ANY OTHER AFFIRMATION OF CTRL EYEWEAR, BY WORDS OR ACTIONS, SHALL CONSTITUTE A WARRANTY.

IN NO EVENT SHALL CTRL EYEWEAR'S LIABILITY IN CONNECTION WITH ANY PRODUCT OR SERVICE MADE AVAILABLE TO YOU BY CTRL EYEWEAR EXCEED THE AMOUNT ACTUALLY PAID BY YOU TO CTRL EYEWEAR FOR ANY SUCH PRODUCT OR SERVICE. IN NO EVENT SHALL CTRL EYEWEAR BE LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH ANY PRODUCT OR SERVICE MADE AVAILABLE BY CTRL EYEWEAR.

SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF CERTAIN WARRANTIES OR THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THOSE PROVISIONS SET FORTH ABOVE MAY NOT APPLY TO YOU.